

Cutting templates for egde protectors

DIY instructions: http://www.benvelo.com/reflector_lightbox.htm

Fits 20 or 10 mm thick sheets and a 3 mm (1/8 inch) shock cord

Make 4 small marks with a pin/needle to show where to bend

